

# Bungee Run

## Operating Procedures

DO NOT operate the Game with winds in excess of 20 M.P.H., or at temperatures less than 40°F.

Check stakes regularly to ensure they are tight.

Check the Blower Fan / Inflation Tube regularly to ensure there isn't any air leakage around fan cone.

Check the GFI connection and breaker at least once per event after the initial set-up of the Game.

Observe maximum occupancy rules for that Game.

Operator should make sure that no one enters the Game with shoes on, eyeglasses, or sharp objects in their hair, clothing or on their person.

Prohibit excessive rough housing by participants

### **THE FOLLOWING MUST BE READ AND ADHERED TO BY EVERY INDIVIDUAL OPERATING THE INFLATABLE GAME**

Operator should point out and make participants aware of the posted warning labels and safety rules.

Operator should remove any debris from the area prior to allowing participants on the Inflatable Game.

Operator should observe persons at all times while they are on an Inflatable Game. Operator should be close enough to be able to warn against flips, piling on, wrestling, climbing on sides/nets, or other horseplay.

Operator should ask anyone doing these things, after being warned once, to exit the Game.

Operator should watch for signs of deflation such as sagging, excessive wrinkling, or distortion. If these are observed, they should ask participants to exit the Game safely and remain calm, as there is no danger.

Operator should keep all spectators outside the Game and maintain at least a 3-foot perimeter away from it.

Operator must be familiar with all State and Local guidelines pertaining to the use and operation of Inflatable Games in their area.